

TSitouch Projected Capacitive (PCAP) Interactive Display Cleaning

Exposed Elements:

The PCAP touch screen consists of two elements exposed to the end user:

- Protective tempered cover glass
 - Covers the entire face of the display
- There are no touch elements exposed to the end user
- Powder coated cold rolled steel housing (Bezel)



CAUTION: Follow the instructions to clean the interactive flat panel. Not following these instructions may result in damaging the product components and void the warranty.

CAUTION: Do not use permanent or dry-erase markers on the screen. If dry-erase markers are used on the screen, remove the ink as soon as possible with a lint-free, non-abrasive cloth.

CAUTION: Do not use any chemical solvents such as acidic or alkali solution.

CAUTION: Do not use abrasive cleaning products that will scratch glass.

CAUTION: Do not apply cleaning solution directly to the touch screen. Apply cleaning solution to cloth. Then use the cloth to clean the screen.

Cleaning Directions:

Step 1: Power Off The Display



Step 2: Apply Solution



Apply cleaning solution directly onto a lint-free, non-abrasive soft cloth

Spraying the cleaner/solution directly on the touch screen may cause damage to touch components and display

Step 3: Clean the Glass



Wipe the glass surface using circular motions to avoid smudges and streaks

Step 4: Inspect



Inspect the touch screen glass. Repeat cleaning as required until touch screen glass is dust and smudge free

Limited removal of permanent marker, dry marker, and other difficult to remove marks from the face of the cover glass can be accomplished using any non-abrasive cleaner suitable for glass cleaning.

Very limited removal of permanent marker, dry marker, and other difficult to remove marks from the face of the display can be accomplished using alcohol if extreme care is taken. Repeated use of alcohol to clean the display could result in damage to the touch solution.